

AVANT GUARD

SMART HOME

D11 New Smart Lock

Complete User Settings Guide

HOW TO ENTER SETTINGS MODE

STEP 1 — FIRST TIME Press 1# <i>In initialization state, Press 1# to enter. Initial administrator is 1234568.</i>	STEP 2 Verify Admin <i>Verify your Admin info: Scan Fingerprint, Enter Password, or Scan Card.</i>	STEP 3 MENU <i>You are now in Settings Mode. Select a number to proceed.</i>
---	--	--

Important Notes:

- The initial administrator number is 001 and CANNOT be deleted here — it must be restored at the factory setting.
- Admin numbers 002-010 can be deleted.
- The administrator who enters the menu cannot delete themselves.

MAIN MENU

OPTION	ACCESS CODE	DESCRIPTION
Add Admin Setting	Press 1#	Add a new administrator with fingerprint, password, or card credentials.
Add Regular User	Press 2# + Verify Admin	Register a new regular user who can unlock but cannot access settings.
Delete User	Press 4# + Verify Admin	Remove a user from the lock — select credential type and confirm with #.
Date Time Setting	Press 8# + Verify Admin	Set the lock's internal clock (Year, Month, Date, Hour, Minute, Second).
Tamper Alarm	Press 01# + Verify Admin	Switch the tamper alarm state On or Off.
Free Passage Mode		Enables free passage — unlock once more to turn OFF Passage Mode.

	After Unlock (Scan Fingerprint/Card/Password) + Press 5#	
Volume Setting	Press 21# + Verify Admin	Adjust volume level: 0=Off, 1=Low, 2=Medium, 3=High.
Double Verify	Press 31# + Verify Admin	Toggle between Single Verify (1) and Double Verify (2) mode.
System Query	Press 51# + Verify Admin	View registered users. Press 2 to turn page Up, Press 5 to turn page Down.
Language Setting	Press 8# + code + #	Change the lock's language using a code number (see below).
Add WiFi	Press 9# + Verify Admin	Add the lock to the Smartlife App for remote access.
Initialization Setting	Press 888#+ Verify Admin	Factory reset — erases all users and returns lock to factory defaults.

ADD ADMIN SETTING — Register Administrator

In initialization state, press 1# and verify with Admin info (Scan Fingerprint, Enter Password, or Scan Card). Enter your Admin information to register.

ADD REGULAR USER — Register New User

Press 2# then Verify Admin. Enter the new user's information — scan fingerprint, enter password (6-8 digits), or scan card.

DELETE USER — Remove Access

Press 4# then Verify Admin. Select the user information to be deleted (fingerprint, card, or password) and press # to confirm deletion.

VOLUME SETTING — Adjust Sound Level

CODE	VOLUME LEVEL
0	Off (Silent)
1	Low Volume
2	Medium Volume
3	High Volume

LANGUAGE SETTING — Change Language

Press 8# followed by the language code, then press # to confirm.

CODE	LANGUAGE
11	English
12	Portuguese
13	Spanish
14	French
15	Arabic
16	Indonesian
17	Vietnamese
18	Chinese
19	Thai

FREE PASSAGE MODE

After unlocking with any credential (Scan Fingerprint / Card / Password), press 5# to activate Passage Mode. The lock will stay unlocked. Unlock one more time to turn OFF Passage Mode and restore normal locking.

INITIALIZATION (FACTORY RESET)

Steps: Press 888# then Verify Admin.

Warning: All users, settings, and stored data will be permanently erased. The lock will return to factory defaults. Use only as a last resort.

ADD Wi-Fi — Connect to Smartlife App

Press 9# then Verify Admin. The lock will enter pairing mode. Open the Smartlife App on your phone and add the device to complete Wi-Fi setup.

QUICK TIPS

Initial admin password: 1234568. Change this immediately after first setup for security.

Double Verify: Adds an extra layer of security — two different credentials are required to unlock the door.

System Query: Use Press 51# to view all registered users and scroll through the list.

Date/Time: Keep the lock's clock accurate for proper access logging and time-restricted credentials.

Tamper Alarm: Keep tamper alarm ON in residential settings to detect forced entry attempts.