

AVANT GUARD

SMART HOME

MODEL D31 PRO New Smart Lock

Complete User Settings Guide

HOW TO ENTER SETTINGS MODE

Each function is accessed by pressing its numbered key and then verifying with admin credentials (Scan Fingerprint, Enter Password, or Scan Card). The initial administrator number is **001** and cannot be changed. Admin number 002-010 can be deleted. The administrator who enters the menu cannot be deleted.

Default Admin Number: 001 — cannot be deleted or changed. Secure this credential carefully.

MAIN MENU — FUNCTION OVERVIEW

KEY	FUNCTION	ACCESS METHOD
1#	Add Admin Setting	In initialization state: Press 1# and verify Admin (Initial password: 12345@#)
2#	Add Regular User	Press 2# and verify Admin info
4#	Delete User	Press 4# and verify Admin, then enter user info to delete + press #
8#	Date Time Setting	Press 8# and verify Admin — enter Year:Month:Day / Hour:Minute:Second
0#	Tamper Alarm	Press 0# and verify Admin — switch state On/Off
5#	Free Passage Mode	Press 5# — after unlock (Scan/Card/Password), passage mode is ON; unlock once more to turn OFF
21#	Volume Setting	Press 21# and verify Admin: 0=Off, 1=Low, 2=Medium, 3=High
31#	Double Verify	Press 31# and verify Admin: Press 1=Single Verify, Press 2=Double Verify

51#	System Query	Press 51# and verify Admin: Press 2=turn page Up, Press 5=turn page Down
89## + code + #	Language Setting	Codes: 11=English, 12=Portuguese, 13=Spanish, 14=French, 15=Arabic, 16=Indonesian, 17=Vietnamese, 18=Chinese, 19=Thai
5#	Add WiFi	Press 5# and verify Admin — add devices on Smartlife App
8889#	Initialization Setting	Press 8889# and verify Admin to reset lock

ADDING USERS

Add Admin (Press 1# + Verify Admin)

Enter your Admin information: Scan Fingerprint (5 times), Enter Password (6-8 digits), or Scan Card.

Add Regular User (Press 2# + Verify Admin)

Enter user information: Scan Fingerprint (5 times), Enter Password (6-8 digits), or Scan Card.

DELETING USERS (Press 4# + Verify Admin)

Enter the information of the user to be deleted (Fingerprint/Card/Password), then press # to confirm deletion.

VOLUME SETTING (Press 21# + Verify Admin)

KEY	VOLUME LEVEL
0	Off (Silent)
1	Low
2	Medium
3	High

LANGUAGE SETTING (Press 89## + code + #)

CODE	LANGUAGE	CODE	LANGUAGE
11	English	15	Arabic
12	Portuguese	16	Indonesian
13	Spanish	17	Vietnamese
14	French	18	Chinese

	19	Thai
--	----	------

QUICK TIPS

Credentials supported: Fingerprint (scan 5 times), PIN (6-8 digits), and IC Card.

Free Passage Mode: Unlocks door and keeps it open. Unlock once more (any credential) to turn passage mode OFF.

Double Verify: Set with 31# — requires two credentials for entry, increasing security significantly.

Admin 001: The initial admin account cannot be deleted. Keep its credentials safe as it is the master access.

WiFi: Press 5# and verify admin to enter Smartlife App pairing mode.