

AVANT GUARD

SMART HOME

F11 Smart Lock

Complete User Settings Guide

ENTERING SETTINGS MODE

STEP 1 Press * <i>Wake keypad, press the asterisk key</i>	STEP 2 Press # <i>Enter settings trigger</i>	STEP 3 Verify Admin <i>Authenticate with fingerprint, card, or password</i>
---	--	---

MAIN MENU OVERVIEW

#	MENU ITEM	DESCRIPTION
1	Add User	Register Master or Normal users via fingerprint, card, or password
2	Delete User	Remove users by ID or by biometric/card/password identification
3	System Setting	Configure unlock, voice, language, time, re-setting, dismantle, and networking
4	Networking	Connect lock to Smartlife App
5	System Query	View system information and logs

1 — ADD USER

OPTION	METHOD	DETAILS
1	Add Master User	Fingerprint / Card / Password
2	Add Normal User	Fingerprint / Card / Password

2 — DELETE USER

OPTION	METHOD	DETAILS
1	Delete By ID	Enter the user ID number to delete
2	Identify Deletion	Enter user information (Fingerprint / Card / Password) to identify and delete

3 — SYSTEM SETTING

SUB-MENU	OPTIONS / VALUES
Unlock Setting	1 — Single Verify 2 — Double Verify
Voice Setting	1 — Low Volume 2 — Medium Volume 3 — High Volume Press 0 for Silent Mode
Language Setting	1 — Chinese 2 — English
Time Setting	Format: YYYY / MM / DD
Re-Setting	Restore default settings
Dismantle Setting	1 — Switch On 2 — Switch Off

4 — NETWORKING

ACTION	DETAILS
Connect To Apps	Pair the lock with the Smartlife mobile application

5 — SYSTEM QUERY

View system status, user counts, and firmware information.

QUICK SETUP NOTES

Fingerprint Registration: Scan 5 times for reliable recognition.

Password Registration: Use 6–8 digits.

First-Time Admin Setup: Press * # → Enter 123456# → Add new admin credentials immediately.

Tip: Register both fingerprint and password for your admin account to ensure backup access at all times.

