

# AVANT GUARD

SMART HOME

## G10 Smart Grille Lock

Complete User Settings Guide

### ENTERING ADMIN SETTINGS

|                                                                                         |                                                                                           |                                                                                              |
|-----------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------|
| <p>STEP 1</p> <p><b>Press * #</b></p> <p><i>Wake keypad and trigger admin entry</i></p> | <p>STEP 2</p> <p><b>Admin Password</b></p> <p><i>Enter the administrator password</i></p> | <p>AUTHENTICATED</p> <p><b>Admin Menu</b></p> <p><i>Full access to all admin options</i></p> |
|-----------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------|

### MAIN MENU OVERVIEW

| SECTION         | ACCESS                        | DESCRIPTION                                             |
|-----------------|-------------------------------|---------------------------------------------------------|
| Admin Setting   | Press * # + Admin Password    | Add/delete users, enable passage/mute modes, add master |
| Lock Reset      | Press * # + Admin Password    | Reset the lock to factory state                         |
| WiFi Setting    | Press * # + Admin Password    | Add device to WiFi / Smartlife App                      |
| WiFi Change     | Lock Reset                    | Change WiFi network via settings reset                  |
| Language Change | Lock Reset → Enter 555666333# | Change display language                                 |

### ADMIN SETTING — Add User

| METHOD      | PROCEDURE            |
|-------------|----------------------|
| Fingerprint | Scan fingerprint     |
| Card        | Scan card            |
| Password    | Enter Password + "#" |

## ADMIN SETTING — Delete User

| METHOD      | PROCEDURE                      |
|-------------|--------------------------------|
| Fingerprint | Scan fingerprint to delete     |
| Card        | Scan card to delete            |
| Password    | Enter Password to delete + "#" |
| By ID       | Enter ID to delete + "#"       |

## ADMIN SETTING — Special Modes

| OPTION                        | DETAILS                                   |
|-------------------------------|-------------------------------------------|
| Enable / Disable Passage Mode | Toggle free passage (door stays unlocked) |
| Enable / Disable Mute Mode    | Toggle voice prompts on/off               |

## ADMIN SETTING — Add Master

| METHOD      | PROCEDURE                        |
|-------------|----------------------------------|
| Fingerprint | Scan fingerprint for 6 times     |
| Card        | Scan card                        |
| Password    | Enter Password + "#" for 2 times |

## LOCK RESET

| STEP        | ACTION                      |
|-------------|-----------------------------|
| Access      | Press * # + Admin Password  |
| Delete User | Enter 666#                  |
| Add User    | Add device on Smartlife App |

## WIFI SETTING

| STEP         | ACTION                                  |
|--------------|-----------------------------------------|
| Access       | Press * # + Admin Password              |
| WiFi Setting | Configure and connect via Smartlife App |

## LANGUAGE CHANGE

| STEP | ACTION             |
|------|--------------------|
| 1    | Perform Lock Reset |
| 2    | Enter 555666333#   |

#### QUICK SETUP NOTES

**G10 Grille Lock Note:** This is a smart grille gate lock. The admin entry uses \* # + Admin Password sequence.

**Master Registration:** Requires fingerprint scan 6 times (more than regular user's standard scan) for higher security.

**Passage Mode:** Enables free entry without authentication — useful for events or open access periods. Remember to disable when not needed.