

AVANT GUARD

SMART HOME

MODEL G43 Smart Lock

Complete User Settings Guide

HOW TO ENTER SETTINGS MODE

Touch to wake the screen, then press # and enter administrative verification.

Security Note: In factory state any fingerprint can unlock the door. Add an administrator password and fingerprint immediately to secure the lock.

MAIN MENU

MENU	FUNCTION
1 Manage User	Add Users (Admin/Guest), Delete User, Clear All User, Read Data
2 System Settings	Set parameters, Volume, Wireless, Date/Time
3 Choose Language	Chinese / English

1 MANAGE USER

Add Users

USER TYPE	CREDENTIALS SUPPORTED
Add Admin	Add Face ID / Add Palm Vein / Add Others (Fingerprint x5, Card, Password 6-8 digits)
Add Guest	Add Face ID / Add Palm Vein / Add Others (Fingerprint x5, Card, Password 6-8 digits)
Set Unlock Period	Input current time and end time (Year/Month/Day Hour/Minute) to limit access window

Delete User

METHOD	ACTION
--------	--------

Delete Face ID	Scan face to delete
Delete Palm Vein	Scan palm to delete
Delete others	Scan fingerprint/card or enter password to delete

Clear All User

Press * to cancel or press # to confirm clearing all users.

Read Data

Press # Next / press 8 Back to browse stored user data and access records.

2 SYSTEM SETTINGS

1 Set Parameters — Lock Mode

OPTION	VALUES
Set the lock mode	1 Automatic lock / 2 Manual lock — Enter time
Set the unlocking hold time	Enter hold time (00-99 seconds)
Face sensor distance	Turn Up: Far (0-4) / Turn Down: Near (4-0)

2 Volume Setting

OPTION	ACTION
Volume UP	Increase speaker volume
Volume Down	Decrease speaker volume

3 Wireless Setting

OPTION	ACTION
Turn on wireless device	Open Smartlife Apps, Connecting EZ Mode
Turn off wireless device	Disable wireless/remote control

4 Date Time Setting

Set Year / Month / Day / Hour / Minute.

3 CHOOSE LANGUAGE

OPTION	LANGUAGE
1 Chinese	Voice prompts in Chinese (Mandarin)

2 English

Voice prompts in English

QUICK TIPS

Credentials supported: Face ID, Palm Vein, Fingerprint (x5), IC Card, Password (6-8 digits).

Face sensor distance: Adjust how far away the face camera can detect — Far=0-4, Near=4-0.

Guest with Unlock Period: Set time-limited access — automatically expires when the period ends.

Wireless via Smartlife App: Turn on wireless and use EZ Mode in the app to connect.