

AVANT GUARD

SMART HOME

MODEL P11 Smart Lock

Complete User Settings Guide

HOW TO ENTER SETTINGS MODE

Press * # + **Admin Password** to enter Admin Setting mode.

MAIN MENU

MENU	FUNCTION
Admin Setting	Wireless Setting, Add User, Delete User, Lock Function
Maintenance Menu (Initial State)	Press 888# — Motor Direction, Rotation Time, Autolock
Factory Reset	Insert pin into reset button between Lock Unlock Button, press and HOLD 8 seconds, press # to confirm

ADMIN SETTING

Wireless Setting

OPTION	ACTION
1 Add Module	Add Device on Smartlife App
2 Delete Module	Remove the connected wireless module

Add User

CREDENTIAL	STEPS
Fingerprint	Scan Fingerprint 4 times
Password	Enter Password + # (repeat 2 times)
Card	Scan card on reader

Delete User

Enter user ID to delete + #

Lock Function

SUB-MENU	OPTION	VALUES
1 Function Settings	Enable / Disable Dual Verify	Two credentials required
	Enable / Disable Alarm	Anti-tamper alarm on/off
	Enable / Disable Mute	Silent mode on/off
2 Volume Settings	Volume Up	Increase volume
	Volume Down	Decrease volume
3 Language Settings	Chinese	Chinese Mandarin prompts
	English	English prompts
4 More Setting	Time Setting / Record / Initialize	Set time, view logs, or factory reset

Add Admin

CREDENTIAL	STEPS
Fingerprint	Scan Fingerprint 4 times
Password	Enter Password + # (repeat 2 times)
Card	Scan card on reader

MAINTENANCE MENU (Press 888#)

OPTION	VALUES
1 Motor Direction	1 Forward / 2 Reverse
2 Rotation Time	Press 1
3 Autolock	1 Disable / 2 Enable 20s

QUICK TIPS

Credentials supported: Fingerprint (4 scans), Password, IC Card.

Dual Verify: Two credentials needed to open — enhanced security for high-value areas.

Maintenance Menu: Access via 888# in initial state — configure motor direction and auto-lock timing.

Factory Reset: Insert pin into reset hole, hold 8 seconds, then press # to confirm. All data erased.