

AVANT GUARD

SMART HOME

P23 Smart Lock

Complete User Settings Guide

SETTINGS ENTRY

STEP 1 *# Press * then # to enter Admin mode	STEP 2 Verify Enter Admin Password. Default: 1234568	NOTE — At initialization state, default admin password is 1234568
--	---	--

MAIN MENU

#	Menu Item	Description
1	Add User	Register new user credentials
2	Delete User	Remove existing user credentials
3	System Setting	Date/Time, Installation, Face, Network, Function settings
4	System Query	User count and record inquiry

1. ADD USER

Sub-Menu	Method	Action
Add Admin	Fingerprint / Password / Card	Scan Fingerprint 5x / Enter 6–8 Digit Password / Scan Card
	Face	Enroll Face (Up/Down/Right/Left)
	Palm Vein	Scan Palm
	Add Fingerprint / Password / Card (same as Admin methods)	
Add User	Fingerprint / Password / Card	Scan Fingerprint 5x / Enter 6–8 Digit Password / Scan Card

	Face	Enroll Face (Up/Down/Right/Left)
	Palm Vein	Scan Palm

2. DELETE USER

Sub-Menu	Action
Verify Delete	Scan face / palm / fingerprint / card directly
Delete By ID	Enter ID to delete then #

3. SYSTEM SETTING

Sub-Menu	Option	Values
Date/Time Setting	Date & Time	Input Time (Year/Month/Day Hour:Minutes)
Installation Setting	Open Direction	Left / Right
	Delay Lock	Disabled / 10–25 Sec
Installation Setting > Lock Setting	Tamper Alarm	Enable / Disable
	Motor Torque	Low / Medium / High
	Lock Back Time	12–9 Sec
	Dwell Alert	On / Off
	Auto Detect	Disable / Enable / Smart Mode
	Detection Distance	N / 15 / 20 / 25
	Recognition Prompt	Enable / Disable
Face Setting	Face Detection	Configuration for face recognition
Network Setting	Network	Connect to network
Function Setting	Volume	Silent Mode / High / Medium / Low
	Dual Authentication	Enable / Disable
	Back / Confirm	* Back / # Confirm
Factory Reset	Reset	* Back / # Confirm

4. SYSTEM QUERY

Sub-Menu	Option	Values
User Count	—	Display total registered users
Record Inquiry	Query By Order	8 Forward / 2 Previous
	Query By Time	Enter Date/Time#

AUTHENTICATION METHODS

Method	Details
Fingerprint	Scan 5 times for accurate registration
Face	Enroll face: Up / Down / Right / Left positions
Palm Vein	Scan palm for registration
Password	6–8 digit numeric PIN
Card (IC)	Scan RFID/IC card

NOTES & TIPS

Default Admin Password: 1234568

Fingerprint Registration: Scan 5 times for best accuracy.

Password: Must be 6–8 digits.

Factory Reset: Press * to go back, # to confirm.