

AVANT GUARD

SMART HOME

P32 Smart Lock

Complete User Settings Guide

SETTINGS ENTRY

STEP 1 *# Press * then # to wake and enter admin mode	STEP 2 Verify Verify admin info (fingerprint / password / card)	NOTES — Fingerprint: Scan 5 times. Password: 6–8 digits and 4. First time: Press *# → Enter 1234568# to add new admin.
---	---	---

MAIN MENU

#	Menu Item	Description
1	Admin Setting	Manage admin accounts (Add/Add Face/Delete Admin)
2	User Setting	Manage user accounts (Add/Add Face/Delete User)
3	System Setting	General, Factory, Network Configuration
4	Record	Query by time/number, storage info, version

1. ADMIN SETTING

Sub-Menu	Option / Action	Details
Add Admin	Enter ID Number (Eg: 00) and #	Scan Fingerprint/Password#/Card → Enter Admin Info
Add Face	Adjust Face Position	Straight, Up, Down, Left, Right
Delete Admin	Enter ID Number and #	Delete specified admin account

2. USER SETTING

Sub-Menu	Option / Action	Details
Add User	Enter ID Number (start from 01–100)	Scan Fingerprint/Password#/Card
Add Face	Adjust Face Position	Straight, Up, Down, Left, Right
Delete By ID	Enter ID Number	Delete specific user by ID
Delete All	Press # To Confirm	Delete all users
Set Datetime	YEAR/MONTH/DAY	Set current date
Locknum	—	Lock number configuration

3. SYSTEM SETTING — GENERAL SETTING

Sub-Menu	Option	Values
Language/ Sound	Volume	Press 4 to Lower / Press 8 to Higher
Unlock Set	Single Mode	Single authentication
	Double Mode	Dual authentication required
	Lock Delay	Press 2 for Higher Second / Press 8 for Lower Second
	Disable Set > Face	Disable face recognition
	Disable Set > PIN	Disable PIN entry
Factory Setting	Factory Reset	Restore factory defaults
Net Configuration	Smart Link	Smart network pairing
	Hot Link	Hotspot network link

3. SYSTEM SETTING — AUTOMATIC LOCK

Sub-Menu	Option	Values
Lock Set	No Push	No Push (Auto Lock without Motor Action)
	Push	Arm lock with motor action
	Delay Lock	Press 3 to High / Press 8 to Lower
Motor Power	Small	Low motor torque
	Mid	Medium motor torque

	Big	High motor torque
Motor Set	Open Direct (L/R)	Press 2 to High / Press 8 to Low
	Reverse	Reverse motor direction

4. RECORD

Sub-Menu	Option	Details
Query By Time	Enter Date	Search records by date
Query By Number	Input Number ID	Search records by user ID
Storage Info	—	View storage capacity and usage
Version Info	—	View firmware version information

AUTHENTICATION METHODS

Method	Details
Fingerprint	Scan 5 times for accurate registration
Face	Adjust position: Straight, Up, Down, Left, Right
Password (PIN)	6–8 digits followed by #
Card (IC)	Scan RFID/IC card

NOTES & TIPS

Default Admin Password: 1234568#

Password Length: 6–8 digits and 4 characters.

Motor Set: Configurable for left/right door direction.

Unlock Modes: Single Mode (one credential) or Double Mode (two credentials required).

Network: Smart Link or Hot Link available for connectivity.