

AVANT GUARD

SMART HOME

P40 Smart Lock

Complete User Settings Guide

SETTINGS ENTRY

STEP 1 * # Press * # and verify admin info	STEP 2 Verify Authenticate with fingerprint, face, card, or password	FIRST TIME Init At initialization, any first info you enter (Password/Fingerprint/Card) will be set as Admin
--	--	--

MAIN MENU

#	Menu Item	Description
1	Add User	Register Admin and regular user credentials
2	Delete User	Remove enrolled credentials
3	System Setting	Datetime, Install, Face, Network, Function settings
4	System Query	User count and record inquiry

1. ADD USER

Category	Method	Action
Add Admin	Fingerprint	Scan fingerprint 5 times / add 6–8 digit password / scan card
	Face	Add Face – Enroll Face
	Palm	Add Palm
Add User	Fingerprint	Scan fingerprint 5 times / add 6–8 digit password / scan card
	Face	Add Face – Enroll Face

	Palm	Add Palm
--	------	----------

2. DELETE USER

Sub-Menu	Action
Verify Delete	Enter user info to delete
Delete By ID	Enter user ID to delete

3. SYSTEM SETTING

Sub-Menu	Option	Values
Datetime Setting	Date & Time	Year/Month/Day Hour/Minute
Install Setting — Direction & Delay	Direction	Right / Left
	Delay Lock	Off / 10 / 15 / 20 / 25
Install Setting — Lock Set	Tamper Alarm	Enable / Disable
	Motor Torque	High / Medium / Low
	Lock Back Time	2–9 Seconds
	Dwell Alert	Disable / 15 / 20 / 25
	Auto Detect	Enable / Disable / Smart Mode
Install Setting — Face Set	Distance	Near / Medium / Far
	Prompt	Enable / Disable
Network Setting	Network	Configure network connectivity
Function Setting	Volume Setting	Mute / Low / Medium / High
	Double Authentication	Enable / Disable
Factory Reset	Reset	Press * to back / Press # to confirm

4. SYSTEM QUERY

Sub-Menu	Option	Details
User Count	—	Display total registered users
Record Inquiry	Query by Order	2 back / 8 next

	Query by Time	Search by date/time
--	---------------	---------------------

AUTHENTICATION METHODS

Method	Details
Fingerprint	Scan 5 times for accurate registration
Face	Enroll face via Face recognition module
Palm	Palm scan registration
Password (PIN)	6–8 digit numeric code
Card (IC)	Scan RFID/IC card

NOTES & TIPS

Initialization: At first setup, any credential entered (Password/Fingerprint/Card) will be set as Admin.

Fingerprint Registration: Scan 5 times for best accuracy.

Password: Must be 6–8 digits.

Double Authentication: Requires two credentials to unlock when enabled.

Factory Reset: Press * to cancel, press # to confirm reset.